

Accessories For Vans Ltd

VW Caddy 2004 on – Near Side Loading Door



Thank you for choosing to purchase a plywood lining kit from Accessories for Vans Ltd.

Our business is founded upon the 'Quality not Compromise' value and we have taken great care to ensure our products are of the highest quality, and are designed in such a way that they can be fitted with the minimum of effort.

Enclosed within your kit you will find all the components you require with which to protect your van. The tools you will require to enable you to complete the fitting of this kit are a Drill, a Cordless drill is recommended for ease of use, and a Sealant Gun.

Should you have any questions or feedback relating to our products, please contact us on 01908 395 559.

IMPORTANT NOTES

Please Read these notes carefully before attempting to fit the ply lining kit to the vehicle.

- Please check the contents of your kit carefully against the contents list supplied. If you find any shortages, please contact us immediately.
- When checking the contents, you may find you have additional fixings. These have been provided to allow for any lost and/or damaged fixings.
- When fitting a ply lining kit, care should be taken to ensure the correct length of fixing is used. We have taken care to pre-drill the ply panels at points which have sufficient room for a screw type fixing when attaching to the panel to the van. However, Accessories For Vans Ltd cannot accept responsibility for the damage caused through the incorrect installation of the kit. The fixings supplied are only a suggested way of attaching the panels to your vehicle and in no way are we implying this is the only method of securing them into place.
- Care must always be taken when fitting side panels to check for obstructions/wiring looms.
- Care must be taken when fitting floor panels. Use only ¾" screws and check for obstructions under the van floor to avoid damage. Only screw into the raised ribs on the floor.
- When fitting sides and door panels, it may be necessary to apply pressure to the plywood so that it follows the contour of the van. It is suggested to start by fixing from the top or the bottom and gradually work your way up/down both sides.
- When fixing the panels in place with the screws, it is suggested you set your drill ratchet to a low resistance. Different types of wood have varying properties and some are more resistant to pressure than others. Screwing the panels in too tight may cause the wood to crack and splinter. **Do not fit any extra screws other than the pre-drilled marks unless you check it is safe to do so.**
- As plywood is a natural product, it is not possible for us to match the colour of the timber exactly; however, every effort is made to provide similarly coloured panels where possible.
- In developing our plywood kits we have fitted them to vehicles prior to offering them for sale, to ensure they are of the highest standard. However, as the vehicle manufacturers are constantly changing their products, we have employed an ongoing development program for each kit we offer, and would welcome any comments you may have.

COMPONENTS

Plywood Panels

- A. Near Side Panel (Over the wheel arch)
- B. Off Side Panel (Over the wheel arch)
- C. Side Loading Door Lower Panels
- D. Side Loading Door Upper Panels
- E. Near Side Rear Door Lower Panel
- F. Near Side Rear Door Upper Panel
- G. Off Side Rear Door Lower Panel
- H. Off Side Rear Door Upper Panel
- I. Front Floor
- J. Rear Floor
- K. Near Side Wheel Box (pre built)
- L. Off Side Wheel Box (pre built)

Please note: A diagram is attached to assist in identification of each panel.

Additional Components

1. ½" Self Tapping Screws – Flanged
2. ¾" Self Tapping Screws – Flanged
3. ¾" Self Tapping Screws – Countersunk
4. Modesty Blocks
5. 1x Tube Brown Sealant
6. 2x Aluminium Edging Strip

FITTING INSTRUCTIONS FOR: -

VW Caddy 2004 on – Near Side Loading Door

Please read the 'Important Notes' before fitting this kit

1. Place the **Near Side Panel (A)** to the near side of the van over the wheel arch. The panel will appear too large for the space; push the panel in to follow the contour of the van. Fix using the ½" flanged screws. Check to avoid wiring loom prior to fixing the screws.
2. Place the **Off Side Panel (B)** to the near side of the van over the wheel arch. The panel will appear too large for the space; push the panel in to follow the contour of the van. Fix using the ½" flanged screws. Check to avoid wiring loom prior to fixing the screws.
3. Place the **Side Loading Door Top Panel (C)** against the top half of the side load door. Fix using ¾" Flanged screws.
4. Place the **Side Loading Door Lower Panel (D)** against the top half of the side load door. Fix using ¾" Flanged screws.
5. Place the **Near Side Rear Door Lower Panel (E)** to the lower part of the near side rear door. Fix using ½" Flanged screws. **(Optional, if the rear door has a cargo net, you may wish to leave this panel off.)**
6. Place the **Off Side Rear Door Lower Panel (G)** to the lower part of the off side rear door. Fix using ½" Flanged screws. **(Optional, if the rear door has a cargo net, you may wish to leave this panel off.)**
7. Insert the **Near Side Rear Door Upper Panel (F) & Off Side Rear Door Upper Panel (H)** against the top half of the rear door(s), and secure using the ¾" countersunk screws and modesty blocks at the left and right hand side of the panel.
8. Place the **Front Floor (I)**, and the **Rear Floor (J)** on the floor of the van and fix using the ¾" countersunk screws. Check for obstructions under the van floor to avoid causing damage.
9. Position the **Wheel Arch Boxes (K&L)** over the wheel arches and fix using the x2 ¾" flanged screws in the side of the boxes.
10. Position the **Aluminium Trim** to the floor at the rear and side openings of the van and fix into position using the ½" flanged screws.

11. Seal all joints between the wheel arch boxes, floor and side panels using the **Brown Sealant** provided. Allow time for the sealant to cure (approximately six hours) before touching or exposing to moisture.

